



Porodo Soundtec

POPWAVE True Wireless Deep Bass Earbud

SKU: PDSTBV77



Table of Contents

Preface	2
Specifications	2
Power On and Off	2
Pairing Guide	2
Operation Guide	3
Auto Shutdown and Charging Guide	3
Precautions	4
Disposal	4
Warranty	5
Contact Us	5

Preface

Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference. The wireless connection (TWS) enables true wireless stereo, with distinct left and right channel separation. It delivers high-fidelity (HIFI) sound effects, and both the left and right earphones have complete Bluetooth functionality, allowing each to be used independently.

Specifications

Model Number	PDSTBV77
Input	5V/1A
Case Battery Capacity	200mAh
Earbuds Battery Capacity	25mAh
Charging Interface	Type-C
Music Playtime	Up to 4H
Total Working Time	12H (Battery Life with Charging Case)
Bluetooth	V5.3
Bluetooth Range	>10 meters

Power On and Off

Power On: The headset powers on automatically when removed from the charging compartment.

Shutdown: Press and hold the button for 5 seconds or place the headset back into the charging compartment.

Pairing Guide

1. Turn on the Bluetooth connection on the device you wish to connect with the earbuds.
2. Scan and pair with the device named "PD-STBV77."
3. The device will automatically connect when you remove the earbuds from the charging case.

Operation Guide

Pause/Play: Press the multi-function button on both the left and right earphones.

Previous Song: Double-press the multi-function button on the left earphone.

Next Song: Double-press the multi-function button on the right earphone.

Volume Up: Triple-press the multi-function button on the right earphone.

Volume Down: Triple-press the multi-function button on the left earphone.

Answer an Incoming Call: Press the multi-function button on either the left or right earphone.

Voice Assistant: Press and hold the multi-function button on both the left and right earphones for 2 seconds.

Reject a Call: Press and hold the multi-function button on both the left and right earphones for 2 seconds.

Power Display: Only supports iOS system devices and some Android system devices.

Auto Shutdown and Charging Guide

Intelligent Sleep Mode: If there is no connection, the earphones will automatically power off after approximately 3 minutes.

Automatic Reconnection: After the earphones are powered on again, Bluetooth will automatically reconnect to the previously paired phone.

Automatic Reconnection After Disconnection: If the earphones are disconnected from the phone due to a long distance, they will automatically reconnect when Bluetooth is within a 10-meter range.

Automatic Power Off During Charging: When in playback, sleep, or standby mode, the earphones will power off automatically when placed into the charging case.

Charging Case Charging: When the charging case is plugged into the cradle with the data cable, the indicator light will flash. It will remain solid when fully charged.


Charging Mode: When the earphones are placed into the charging case, the earphones will charge. The indicator light on the charging case will turn off once the earphones are fully charged.

K Precautions

1. Do not treat this product violently or squeeze it with heavy objects. Keep it away from high-temperature and high-humidity environments.
2. Keep away from Wi-Fi routers and other high-frequency transmitting equipment, as this may affect the signal reception, causing sound distortion and disconnection.
3. Use the product in an effective environment (within 15-10 meters), and ensure there are no physical obstructions (such as walls) between the Bluetooth device and the headset.
4. To prevent the battery from failing to charge due to dormancy, keep the charging case above %20 capacity.
5. Keep the product away from children and pets to avoid accidental injury or ingestion of small parts.

K Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**