



**Porodo Soundtec**  
**JETPODS PRO Earbuds**  
**Gen 4 True Wireless**

SKU: PDST2232ZK3

# **Table of Contents**



Schematic View	2
Specifications	3
Function Guide	3
Charging Case Indicator Guide	4
Pairing Guide	4
Notes on Wireless Connection	5
Precautions	5
Disposal	6
Warranty	6
Contact Us	6

Thank you for choosing this product. These true wireless earbuds offer an excellent way to enjoy high-quality sound. Before using the product, please read this User Manual carefully to ensure proper usage. Keep it for future reference.

**Schematic View**

**Ear Cap**

**Ear Cap**



**Touch Area**

**Touch Area**

**Charging Port**

## Specifications

Model	PDST2232ZK3
Charging Input	5V/200mA
Case Battery Capacity	200mAh
Earbuds Capacity	3.7V25mAh
Bluetooth Version	5.4
Talk Time	3H (80% Volume)
Music Playback Time	4.5H (80% Volume)
Recharge Time	1.5H
Transmission Range	10m
Frequency Range	2.402-2.480GHz

## Function Guide

**Power On:** Open the charging case cover to power on the earbuds.

**Power Off:** Place the earbuds back into the charging case and close the cover to turn them off.

**Play/Pause:** Tap once on either the left or right earbud.

**Previous Song:** Triple-tap on the left earbud.

**Next Song:** Triple-tap on the right earbud.

**Volume Increase:** Double-tap on the right earbud.

**Volume Decrease:** Double-tap on the left earbud.

**Voice Assistant:** Press and hold either earbud for 2 seconds.

**Pairing:** Open the charging case cover, and the earbuds will automatically enter pairing mode, waiting for your phone to search and connect.

**Answer Call:** Tap once on either earbud.

**End Call:** Double-tap on either earbud.

**Reject Call:** Press and hold either earbud for 2 seconds.

## Charging Case Indicator Guide

**Open the Charging Case Cover:** The green light will turn on. After 8 seconds, the green light will turn off.

**Charging the Earphones with the Charging Case:** The green light will turn on and will turn off once the earphones are fully charged.

**Charging the Charging Case:** The orange light will flash. Once fully charged, the orange light will stay on continuously.

**Low Battery Reminder for the Charging Case:** The green light will flash to indicate a low battery.

## Pairing Guide

1. Place the wireless earbuds and mobile phone (or other connected devices) close to each other.
2. Ensure the earbuds are powered on. Open the charging case cover or remove the earbuds from the case.
3. Ensure that the left and right earbuds are connected, allowing them to enter pairing mode.
4. Enable the wireless function on your mobile phone (or other wireless device) and search for available devices.
5. The phone will detect all nearby wireless devices. Select the corresponding wireless model name to connect. Once the pairing is successful, you can make calls, listen to music, and more.

## Notes on Wireless Connection

1. Keep the distance between the wireless earbuds and the mobile phone (or other connected devices) within 1 meter for optimal connectivity; the closer, the better.
2. You can place the earbuds in the charging case and open the case cover to initiate the connection.
3. When removing the earbuds from the charging case, ensure that both the left and right earbuds are properly connected.
4. Do not close the charging case cover during the connection process.

## Precautions

1. Never use corrosive cleaning agents to clean this product.
2. Do not expose this product to heat or place it near fire sources, such as cooking stoves.
3. Avoid prolonged exposure to direct sunlight to prevent high temperatures from affecting the product.
4. Do not dispose of this product in fire to prevent the risk of explosion.
5. Do not attempt to disassemble or modify the product, as it does not contain any repairable components.
6. Do not use this product in the rain.
7. If you do not plan to use this product for an extended period, store it in a dry environment. Charge the earbuds at least once a month to maintain their lifespan.
8. Avoid exposure to extreme temperatures and dust.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **[porodo.net/warranty](https://porodo.net/warranty)** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
**[porodo.net/warranty](https://porodo.net/warranty)**

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:  
**[info@porodo.net](mailto:info@porodo.net)**

Website: **[porodo.net](https://porodo.net)**

Service Support: **[support@porodo.net](mailto:support@porodo.net)**

Instagram: **[porodo](https://www.instagram.com/porodo)**