

**PORODO**  
LIFESTYLE



**Porodo Lifestyle**  
**PORTABLE**  
**HAIR STRAIGHTENER**

SKU: PDBL118PK

# Table of Contents

Product Overview	2
Specifications	2
Safety Precautions	3
Setup Guide	4
Disposal	6
Warranty	7
Contact Us	7

## Product Overview

The Porodo Portable Hair Straightener offers a convenient and cordless design, making it ideal for on-the-go styling. It features three adjustable temperature levels, allowing you to customize the heat for your hair type. Its sleek, compact form makes it easy to carry and perfect for travel, ensuring you can maintain smooth and straight hair wherever you are.

## Specifications

Input	DC 5V/2A
Battery Capacity	4000mAh
Rated Power	22W
Working Time	40 Minutes
Recharge Time	3H
Charging Interface	Type-C
Temperature Range	160°C ~ 200°C
Product Size	3.5 × 3.5 × 24cm

Product Weight	211g
Model Number	PDBL118

## Safety Precautions

When using the product, a slight burnt smell may occur, which is a normal phenomenon when the new product is exposed to high temperatures. Please be assured that as you continue using it, the smell will gradually decrease. Before disposing of the appliance, ensure the battery is removed. When removing the battery, the appliance must be powered off. Please dispose of the battery properly.

### **Danger:**

Only use a qualified plug to charge this product, as improper use may damage it. Do not use the product if you have a reduced sensitivity to heat, as it may cause burns or scalds.

If the product is malfunctioning, please stop using it immediately, as it could lead to accidents or serious personal injury. Do not use the product near bathtubs, showers, or basins filled with water.

### **Warnings:**

- 1. Avoid use during showers:** Do not use the product while taking a shower or bath, or near bathtubs, showers, or other water sources.
- 2. Prevent damage:** If the product becomes deformed or damaged, stop using it immediately to avoid electrical shock or fire risks.
- 3. Keep away from flammable materials:** Do not use near flammable or explosive materials (e.g., alcohol, gasoline, nail polish remover). Doing so may cause fire or explosion.
- 4. Handle with care:** Avoid dropping the product. If damaged due to dropping, do not continue use.

- 5. Cool down after use:** Allow the product to cool down for a short period before turning it off or storing it.
- 6. Avoid covering the product:** Do not place any items on the product while it is in use.
- 7. Temperature caution:** The surface of the heating element can reach up to 200°C. Do not place the product on soft cushions or blankets while in operation.
- 8. Warning about heating teeth:** When in use, the heating teeth become very hot. Never touch them directly during operation.
- 9. Flammable substances:** Before use, avoid contact with flammable substances (e.g., styling agents, hair mousse) while using the product.
- 10. Not for individuals with health conditions:** This product is not suitable for use by individuals with physical, sensory, or mental health issues, or those lacking the required knowledge or experience, unless supervised by a guardian.
- 11. Supervision for children:** Ensure children do not use or play with the product without proper supervision.
- 12. Packaging:** Please dispose of packaging materials (e.g., plastic bags) properly, and keep them out of reach of children.
- 13. Not for pets:** This product is not suitable for pets.

## **Setup Guide**

### **A. Key Indicator Light Description**

- 1. Press and hold the power button for 1 second to turn on the device.** The power will automatically remain on for 30 minutes.
- 2. Based on the environmental temperature, use the switch to select the appropriate heat setting.**
- 3. Once the product heats up, the white LED light will correspond to the selected heat gear.** When the product temperature reaches the selected gear, the white LED will remain on.

**4.** Press and hold the power button for 3 seconds to turn the device off. All LED lights will turn off, and heating will stop.

**5.** While charging, the charging indicator light will flash, and once fully charged, the white light will remain on. The device cannot be used while charging.

### **B. Operation Of Charging Straight Hair Comb**

**1.** Ensure the product is used in a dry state for optimal performance; otherwise, the desired styling effect may not be achieved.

**2.** Before charging, confirm the device is turned off to prevent accidental power on during transport.

**3.** When charging, ensure the ambient temperature does not exceed 40°C. Charging time from 0% to 100% is approximately 3-4 hours. When using a plug that exceeds 5.3V for charging, the product will be locked and unable to charge (this may vary slightly depending on the plug type used).

**4.** Please fully charge the product before using it for the first time.

**5.** Fast charging is not supported.

### **C. Temperature Selection Recommendation**

160°C: Dyed, damaged or delicate hair

180°C: Ordinary or slightly curly hair

200°C: Very thick, curly, and rough hair

### **Pre Styling Preparation:**

Clean hair and blow dry, thoroughly comb hair until smooth and free of tangles. After the product is turned on, choose the temperature range that is suitable for your hair quality.

### **Operation of Wireless Straight Hair Comb Direct Hair Usage Operation**

After the product is turned on, press the temperature gear button to adjust to the appropriate temperature according to different hair quality requirements. After heating the product to the set gear temperature, hold the handle by hand and pay attention to the safe distance between the heating teeth and the skin and eyes.

Divide the hair evenly, grip and tighten it, place the hair in the comb from 1-3cm away from the root, slowly and smoothly pull down from the root to the tip, and repeat the above action until the desired straight hair effect is achieved.

After finishing the styling, press and hold the power button for 3 seconds to turn off the machine. After the finished hair cools down, use a comb to comb it.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



## **Warranty**

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at [porodo.net/warranty](http://porodo.net/warranty) and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:  
[porodo.net/warranty](http://porodo.net/warranty)

## **Contact Us**

If you have any questions about this Privacy Policy, please contact us at:

**info@porodo.net**

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**