



**GREEN LION**



**Green Lion**  
**FLUX DRIVE**  
**FM TRANSMITTER**

SKU: GNFLXDRFMCCBK

Model No: GL-CC24

## Table of Contents

Product Overview	2
Specifications	2
Charging Guide	3
Product Components	4
Button Functions	5
Usage Instructions for Music Player	5
Safety Precautions	6
Disposal	7
Warranty	7
Contact Us	7

## Product Overview

The Green Lion FM transmitter is a versatile and convenient in-car accessory that makes your drive less mundane. It is handy, can fit into any car, and features a microphone for hands-free calls. It also supports real-time monitoring, USB, and TF card playback for smooth integration into your car. It also comes with Quick Charge 3.0 technology, allowing for a fast charge of up to 22.5W, adequately keeping your devices powered during the journey. There is a clear LED display with simple operations on a multi-function button. Safety protection is incorporated into this product along with multi-device charging. Make calls or listen to music by enjoying the latest technology in your car for all conveniences while traveling.

## Specifications



Model No.	GL-CC24
Material	ABS+Flame Retardant PC
Input Voltage	12-24V
Bluetooth	V5.3
Transmission Range	5 m
FM Frequency	87.5 - 108.0 MHz

U-disk Support	Up to 32GB
TF Card Support	Up to 32GB
File Formats	MP3/APE/WAV
USB-C Port	5V/3A, 9V/3A, 12V/2.5A (PD30W)
USB-A QC3.0 Port	5V/4A, 4.5V/5A, 12V/1.5A (QC22.5W)
USB-A U-disk Port	5V/2.4A (12W Max)
Total Output	64.5W
Product Weight	42.5 g
Product Dimensions	44.6*44.6*80.6 mm

## Charging Guide

1. Insert the car charger into the cigarette lighter port in the car.
2. Connect one end of the charger cable to the output port of the car charger, and the other end to your mobile phone or another digital device. At this point, the device will begin charging.

## Product Components



## Button Functions

1. Left Button: Previous song
2. Right Button: Next song
3. Long-press the Left Button: Switch to the previous folder
4. Long-press the Right Button: Switch to the next folder
5. Rotate the Knob to the Left: Decrease volume
6. Rotate the Knob to the Right: Increase volume
7. In Music Mode: Short-press the knob to play/pause music
8. In Call Mode: Short-press the knob to answer/end a call
9. Press and Hold the Knob: Enter FM radio mode; rotate left/right to decrease/increase frequency; exits automatically after 3 seconds of inactivity
10. Double-press the Knob: Switch modes (Wireless/USB Drive/TF Card Mode)

## Usage Instructions for Music Player

### 1. Powering On the Player

After starting the car, insert the car charger's plug into the vehicle's cigarette lighter socket. Turn on Wireless Mode first (ensure that no USB drive or TF card is inserted). The transmission frequency and battery voltage will alternate flashing.

### 2. Connecting the Player via Wireless Connection

On your phone, go to [Settings] → [Wireless Mode], turn on Wireless Mode, and search for available devices. When [GL-CC24] appears, tap to connect. A voice prompt will confirm a successful pairing. If the connection fails, check whether the product is properly powered.

### 3. Playing Music from Your Phone

Open your preferred music app on your phone, select your favorite songs, and start playback. The audio will be played through the car's sound system.

#### **4. Playing Music from a USB Drive**

While in Wireless Mode, insert a USB drive containing music files into the USB port labeled "MP3." The player will automatically switch to USB playback mode and start playing music.

#### **5. Playing Music from a TF Card**

While in Wireless Mode, insert a TF card containing music files into the card slot. The player will automatically switch to TF card playback mode and start playing music.

## **Safety Precautions**

- 1.** This product is designed for use with vehicles that have voltages between 12V and 24V only. Do not use it with vehicles that have voltages exceeding 24V, as this may cause irreversible damage to the product.
- 2.** Improper use of this product may cause damage to the product or pose a risk to personal and property safety.
- 3.** This product supports fast charging. For optimal performance, use an official or certified OEM charging cable.
- 4.** Insert your device for charging only after the car engine has started.
- 5.** Do not charge high-power devices to avoid potential damage from excessive power.
- 6.** Do not use the charger in humid environments or during thunderstorms.
- 7.** Avoid cleaning the charger with harsh chemicals or detergents.
- 8.** Remove the plug after use and always use branded data cables.
- 9.** This is an electronic product. Please handle with care and avoid dropping or bumping the product.

## Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.

## Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at <https://www.greenlion.net/warranty> and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:

<https://www.greenlion.net/warranty>

## Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: <https://www.greenlion.net/>

Sales: [sales@greenlion.net](mailto:sales@greenlion.net)

Service Support: [Support@greenlion.net](mailto:Support@greenlion.net)

Telegram: [@greenlion\\_global](https://t.me/greenlion_global)

Instagram: [@greenlion\\_global](https://www.instagram.com/greenlion_global)