



Green Lion
Venice
Wireless Earbuds

SKU: GNVENBUD88

Model No: GL-TWS88

Table of Contents

Product Overview	2
Specifications	2
Bluetooth Connection Guide	3
Touch Control Instructions	3
Charging Status Indicator	4
Safety Precautions	5
Troubleshooting	5
Disposal	6
Warranty	7
Contact Us	7

Product Overview

The Green Lion Venice Wireless Earbuds offer an open-ear audio experience with a secure clip-on design for a comfortable and lightweight fit. They are equipped with 10mm drivers that deliver clear and dynamic sound. With Bluetooth V6.0 technology, these earbuds provide a reliable and fast connection for seamless music and calls. The earbuds come with touch control for easy operation and support USB-C charging for convenience. With up to 4 hours of playtime on a single charge, the Green Lion Venice Wireless Earbuds are perfect for users who seek both functionality and comfort in their daily audio needs.

Specifications

Material	ABS
Case Battery	400mAh
Earbuds Battery	30mAh
Bluetooth	V6.0
Transmission Range	10m
Speaker	φ 10mm
Frequency	2.402–2.480GHz

Impedance	16Ω
Sensitivity	117±3dB S.P.L at 1kHz
Charging Port	Type-C
Charging Time	About 1.5hrs
Playtime	4hrs continuous playtime, 32hrs total playtime with charging case
Standby Time	About 12hrs
Product Weight	47.8g ± 1g
Product Dimensions	28.7 × 52.6 × 65.5mm

Bluetooth Connection Guide

1. Remove the earphones and bring them close to your unlocked phone.
2. Wait for about eight seconds for the Bluetooth to turn on.
3. Search for the Bluetooth name "GL-TWS88" and select it to connect.

Auto-Connect: The phone will retain the connection through the headset's matching name. When the headset is taken out, it will automatically reconnect.

Touch Control Instructions

- a. Left Ear Touch Control Instructions

1. Double-click: Play/Pause, Answer/Hang up
2. Triple-click: Previous song
3. Press: Reduce volume (click the multifunction button on the left side)
4. Press and hold (for 2 seconds): Reject call
5. Long press (for 1.5 seconds): Activate voice assistant



b. Right Ear Touch Control Instructions

1. Double-click: Play/Pause, Answer/Hang up
2. Triple-click: Next song
3. Press: Increase volume (click the multifunction button on the right side)
4. Press and hold (for 2 seconds): Reject call



Charging Status Indicator

1. When charging the case: The white light will flash.
2. When the charging case is fully charged: The orange light will stay on.

Safety Precautions

1. Use a cotton swab to clean the charging surface of the earphones, as it may get dirty.
2. The earphones should be used as directed. Keep the distance between the phone and the earphones within 8 meters for a stable connection.
3. If the earphones do not connect or there are communication issues, remove the earphones and accessories. Do not use a charging adapter with a higher ampere rating than recommended.
4. Ensure the earphones are fully charged before use to guarantee proper performance.

Troubleshooting

1. **Overheating or Damage During Charging:** If your earbuds overheat or get damaged while charging, check if you are using a charger with over 5V/2A power. If so, replace it with a charger that has under 5V/2A power.
2. **Only One Earbud Has Sound:** Place both earbuds back into the charging case; they will turn off automatically. On your phone, cancel the Bluetooth pairing. Open the charging case, take out the earbuds, and hold them close to your unlocked phone. Wait about 8 seconds, then search for the Bluetooth pairing name on your phone and tap to reconnect.
3. **No Sound from Earbuds:**
 - 3.1. Confirm that the earbuds are turned on and in working condition.
 - 3.2. Check if the earbuds' volume level is appropriate.
 - 3.3. Ensure the earbuds are properly connected to your phone.
 - 3.4. Make sure the earbuds are within their normal working range.

4. Intermittent Sound:

4.1. In areas with strong signal interference, Bluetooth earbuds may experience interruptions or background noise. Move to another location, disconnect, and reconnect to resolve this issue.

4.2. Signal transmission may be affected if the earbuds are more than 8 meters away from your phone or if there are obstacles in between.

4.3. Nearby high-power transmitting devices, such as routers or microwaves, may disrupt the signal.

4.4. Dense spaces, like electronics markets, can also interfere with signal transmission.

Disposal

This product must not be disposed of as unsorted household waste. It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Green Lion** website or shop come with a 24-month warranty.

When you buy **Green Lion** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **<https://www.greenlion.net/warranty>** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
<https://www.greenlion.net/warranty>

Contact Us

If you have any questions about this Privacy Policy, please contact us at:

Website: **<https://www.greenlion.net/>**

Sales: **sales@greenlion.net**

Service Support: **Support@greenlion.net**

Telegram: **[@greenlion_global](https://www.instagram.com/greenlion_global)**

Instagram: **[@greenlion_global](https://www.instagram.com/greenlion_global)**