

PORODO
LIFESTYLE



Porodo Lifestyle
LUMIO SMART FHD PROJECTOR

SKU: PDTS17GY

Table of Contents

Product Overview	2
Specifications	2
Package Contents	3
Controller Diagram	3
Remote Control Description	4
Projector Setup and Focus Adjustment	4
Projection Range Guide	6
Software Settings	6
Picture Adjustment	8
Media Player	9
Screen Sharing	10
Safety Precautions	11
Disposal	13
Warranty	14
Contact Us	14


Product Overview

The Porodo LifeStyle LUMIO SMART FHD Projector is a compact and versatile device designed to deliver high-quality visuals and seamless connectivity for both home entertainment and professional presentations. It ensures sharp and vibrant image quality, making it ideal for streaming movies, gaming, or conducting business meetings. This product provides clear images even in moderately lit environments. Overall, the Porodo LUMIO SMART FHD Projector delivers a user-friendly experience without compromising on performance. Before using the product, please carefully read this User Manual to guarantee correct usage and keep it secure for future reference.

Specifications

Input Voltage	100-240V
LCD Panel Size	2.69"
Bluetooth Version	5.0
Brightness	180 ANS
Resolution	1920 x 1080 (Full HD)
Operating System	Android TV
Internal Storage	1GB RAM + 8GB ROM
Speaker Power	3W
Contrast Ratio	2000:1
Aspect Ratio	16:9 / 4:3
Interface	x1 HD Multimedia, x1 USB-A, x1 Audio
Wi-Fi	2.4GHz & 5GHz
Projection Size	30"-100"
Projection Distance	1m-3m
Net Weight	885g
Model Number	PDTS17


Package Contents



Projector




Remote Controller



Power line

Controller Diagram



Remote Control Description


1. Power On/Off: Turn the unit on or off.
2. Mute/Unmute: Mute or unmute the projector's audio.
3. Menu: Open the menu for applications or files.
4. Volume + / -: Increase or decrease the volume.
5. OK/Select: Confirm a selection.
6. Directional Keys: Use the up or down arrows to navigate through the OSD (On-Screen Display), and the left or right arrows to make adjustments.
7. Return: Go back to the previous menu or close the active window.
8. Home: Return to the home screen.
9. Input Source: Switch between different input sources or open removable disks.
10. Zoom In: Adjust the lens focus forward.
11. Zoom Out: Adjust the lens focus backward.
12. Settings/Menu: Access the settings menu.

Projector Setup and Focus Adjustment

By following these guidelines, you can ensure the longevity and efficiency of your projector while minimizing the risk of malfunctions or damage. To ensure the optimal performance and longevity of your projector, please follow these important guidelines:

1. Maintain Adequate Clearance: When using the projector, make sure that there are no obstructions within 30 cm around both the air inlet and air outlet. Adequate space is essential to allow proper airflow.
2. Avoid Exposure to Direct Airflow: Do not install the projector where it is directly exposed to the air conditioning or in areas with high humidity or temperature. Such conditions may cause malfunction or permanent damage to the device.
3. Ventilation: Ensure that the projector is placed in an area with sufficient ventilation. Proper airflow is crucial to prevent hot air from accumulating inside the projector, which could lead to overheating and abnormal operation. Insufficient ventilation or blocked airflow may cause the projector to overheat, leading to potential damage or malfunction. (Refer to the diagram)


- 4. Prevent Foreign Objects:** Avoid placing clips, paper, or any small objects near the machine. Do not allow metal objects to fall into the projector, as this could cause significant damage. If such an incident occurs, immediately turn off the projector and have a qualified technician inspect and repair it.
- 5. Keep Liquids Away:** To avoid the risk of leakage, do not place any liquids near the projector. Liquids can damage the internal components and cause electrical malfunctions.
- 6. Use Proper Packaging During Transport:** When transporting the projector, ensure that you use soft, cushioned packaging materials. This will protect the lens from scratches and other damage. Additionally, always use the lens protection cover to keep the projector safe during transport.
- 7. Handling After Projection:** After projection, the area around the exhaust vents will become hot. Do not touch the exhaust vents with your hands to avoid burns.
- 8. Eye Protection:** Never look directly into the projector lens while the machine is powered on. Direct exposure to the light from the lens can cause serious harm to your eyes.
- 9. Dust Removal:** After using the dust removal window, please close the door properly. Leaving it open may cause serious internal damage to the product.
- 10. Routine Cleaning:** Regularly clean the dust screen of the air inlet to prevent dust buildup, which could block airflow and damage the internal components of the projector. You may use brushes, vacuum cleaners, or other gentle cleaning tools to remove the dust. Be sure to clean the dust screen carefully to maintain optimal performance.



Blurry Image



Projection Range Guide




Software Settings

1. Home page




2. Project Setting




3. Language Setting

Choose the preferred language from the list of available options in the system configuration settings.



4. Time Setting

Select the correct time zone and time format that suits your preference in the system configuration settings.



5. Wi-Fi Setting

Select a Wi-Fi network (also known as a hotspot) from the available list and enter the password to establish a connection.



6. Bluetooth Settings


Open the Bluetooth settings and choose the device you wish to pair with to establish a successful connection.



Picture Adjustment


1. Projection Mode

Select your preferred projection method from the Settings screen.




2. Picture Correction

Go to the settings and select "Manual Keys" to adjust the screen display.



Media Player


1. Insert the USB flash drive into the projector's USB port. The system will detect it automatically and show a pop-up with the available file type. Use the remote control to select the file type and press OK to enter the folder.
2. Press the Input button on the remote and select USB Device to enable the USB input.



Screen Sharing

1. Screen Mirroring

To connect the projector with your mobile device for screen sharing, ensure both are connected to the same Wi-Fi network. You can use the screen-sharing software included with the system to facilitate this connection. Alternatively, you can download compatible screen-sharing applications from the app store of your device for additional options.



2. Additional Operations


From the home page, use the down direction key to navigate and select different applications. You can also customize the desktop by changing the background image and adjusting sound effects to suit your preferences.



Safety Precautions

By following these guidelines, you can ensure the longevity and efficiency of your projector while minimizing the risk of malfunctions or damage. To ensure the optimal performance and longevity of your projector, please follow these important guidelines:

- 1. Maintain Adequate Clearance:** When using the projector, make sure that there are no obstructions within 30 cm around both the air inlet and air outlet. Adequate space is essential to allow proper airflow.
- 2. Avoid Exposure to Direct Airflow:** Do not install the projector where it is directly exposed to the air conditioning or in areas with high humidity or temperature. Such conditions may cause malfunction or permanent damage to the device.
- 3. Ventilation:** Ensure that the projector is placed in an area with sufficient ventilation. Proper airflow is crucial to prevent hot air from accumulating inside the projector, which could lead to overheating and abnormal operation. Insufficient ventilation or blocked airflow may cause the projector to overheat, leading to potential damage or malfunction. (Refer to the diagram)



4. Prevent Foreign Objects: Avoid placing clips, paper, or any small objects near the machine. Do not allow metal objects to fall into the projector, as this could cause significant damage. If such an incident occurs, immediately turn off the projector and have a qualified technician inspect and repair it.

5. Keep Liquids Away: To avoid the risk of leakage, do not place any liquids near the projector. Liquids can damage the internal components and cause electrical malfunctions.

6. Use Proper Packaging During Transport: When transporting the projector, ensure that you use soft, cushioned packaging materials. This will protect the lens from scratches and other damage. Additionally, always use the lens protection cover to keep the projector safe during transport.

7. Handling After Projection: After projection, the area around the exhaust vents will become hot. Do not touch the exhaust vents with your hands to avoid burns.

8. Eye Protection: Never look directly into the projector lens while the machine is powered on. Direct exposure to the light from the lens can cause serious harm to your eyes.

9. Dust Removal: After using the dust removal window, please close the door properly. Leaving it open may cause serious internal damage to the product.

10. Routine Cleaning: Regularly clean the dust screen of the air inlet to prevent dust buildup, which could block airflow and damage the internal components of the projector. You may use brushes, vacuum cleaners, or other gentle cleaning tools to remove the dust. Be sure to clean the dust screen carefully to maintain optimal performance.

Important Notes:

1. Do not open the projector case. Always have maintenance performed by qualified professionals to avoid damage.
2. Uninsulated voltage inside the unit can cause electric shock. Do not touch internal components. Always turn off and unplug the projector before servicing.
3. To prevent electric shock or fire, do not expose the projector to rain, moisture, or excessive humidity

Disposal

This product must not be disposed of as unsorted household waste.

It is important to separate such waste for proper treatment and recycling, in compliance with local waste management regulations.



Warranty

Products that you buy directly from our **Porodo** website or shop come with a 24-month warranty.

When you buy **Porodo** products from any of our approved sellers, you only get a 12-month warranty. If you want to extend this warranty, go to our website at **porodo.net/warranty** and fill out the form with your information. Don't forget to upload a picture of the product too. After we've checked and accepted your request, we'll send you an email to confirm that your product's warranty has been extended.

For more info, please check:
porodo.net/warranty

Contact Us

If you have any questions about this Privacy Policy, please contact us at:
info@porodo.net

Website: **porodo.net**

Service Support: **support@porodo.net**

Instagram: **porodo**